

## Professional 4-Channel Wireless A/V Transmitter & Receiver Kit



The pictures above are for demonstration purpose ONLY; actual look may vary.

**CAUTION:** The transmitter uses regulated DC 12V 2A power supply and the receiver uses regulated DC 12V 1A power supply, both power supplies are provided with the kit. Using incorrect power supplies as well as switching the power supplies for the transmitter and the receiver will cause permanent damages to the devices. Also to avoid permanent damages, antennas for BOTH the transmitter and the receiver MUST be attached before the devices are being powered on. We are not responsible for any damage to the devices caused by end user error. End user of the devices might be required to obtain license to operate the devices, consult your legal advisor. The manufacturer or the seller of the devices cannot be held liable under any circumstances if the devices are used for illegal purposes; offenders are subject to severe legal punishments by government law enforcement agencies.

### **Connecting Instructions**

1. Screw on the transmitting antenna (**note you must attach the antenna before power on the transmitter to avoid permanent damage**).
2. Connect your RCA audio/video source to the transmitter using one pair of RCA A/V cable supplied with the kit.
3. Screw on the receiver antenna (**note you must attach the antenna before power on the receiver transmitter to avoid permanent damage**).
4. Connect the receiver to your monitor or recording device with the other pair of RCA A/V cable supplied with the kit.
5. Power on the transmitter with supplied DC12V 2A power supply.
6. Power on the receiver with supplied DC12V 1A power supply.
7. Power on video source and display monitor/recording device.
8. The transmitter and the receiver should be set at the same default channel. If no signal received, make sure the transmitter and the receiver are at the same channel.
9. Adjust transmitter/receiver antenna if necessary to reach best signal quality.